HabiStat Clear Home - Small


Instructions




Vid<mark>eo Guide</mark>

Note - Peel off the protective layer on each of the acrylic sections. fig0

- 1. Place the **Mesh** and the **Square Panel** onto the Top Panel 9, and using the 4 screws, 4 nuts and the Allen key, secure the Square Panel into place (you may need to carefully pierce a hole through the mesh for the screws to go through) fiq1
- 2. Use the long screw, and large nut to attach the Door Latch 10 to the Door 13 ensuring the long side of the latch is against the door. fig2
- 3. Place the **Base 9** panel on a flat surface. *fig3*
- 4. Slot the **Back** to the base, by putting the anchor points through the slots. Attach 2 bands around the anchor points to secure the panels together. fig4
- 5. Slot the **Substrate Barrier 1** to the front of the enclosure at the base. Attach 2 bands around the anchor points to secure the panels together. fig5
- 6. Slot the **Top Panel @** section to the back. Ensure that the lock slot is facing the front. Attach 2 bands around the anchor points to secure the panels together. fig6
- 7. Slot in a **Side Panel 0** ensuring that the small hole on the side is at the front, just above the Substrate Barrier. Attach 7 bands around the anchor points to secure the panels together. fig7
- 8. Slot in the second **Side Panel 9**, ensuring again that the small hole is at the front, just above the substrate barrier. Attach 7 bands around the anchor points to secure the panels together. fig8

















- Slide the **Door 3** into place by placing the nodules into the small holes at either side of the 2 side panels. fig9
- 10. Optional For higher humidity, place the extra **Ventilated Top Panel ®** on the mesh

Part order:

- Mesh
- **3 Square Panel** square panel with a hole in each corner for securing the mesh
- **G** Top Panel square panel with a door latch slot at the front
- Door Latch
- **9 Door** has a nodule either side of the bottom, and a hole at the top for the door latch
- **6** Base square panel with anchor points in each corner
- 6 Back large rectangular section with anchor points on the side, and anchor holes on the top & bottom
- ❸ Substrate Barrier section with the HabiStat Logo on the front
- Left Side Panel ventilated side panel
- 0 Right Side Panel - ventilated side panel
- Ventilated Top Panel place this panel on top of the Mesh Securing Square should extra humidity be required

Accessories: 20x bands, 4x small screws, 4x small nuts, 1x long screw, 1x large nut, 1x Allen Key, 1x door latch

